

INTERIOR

Installation: Lock-It-Up

The Mopar folks have released a lock kit for the storage compartments of 2010 and newer trucks. The part number: 82211653.

We evaluated the kit, but we did not like the latch-to-plastic interference when the lock was closed. We sourced a different lock kit from the same vendor. We can offer it to you with two benefits: a latch-to-metal interference and a lower cost.

The drawback: our kit requires you to drill two holes into the plastic storage compartment and Dremel out a small recess for the metal latch tab.

**To install the Lock-It-Up
the instructions are as follows:**

- 1) Using a Torx bit, remove the four screws holding the plastic storage compartment in the truck and lift it out.



- 2) Using a Phillips head screwdriver, remove the existing plastic release handle and install the metal "Lock-It-Up" release handle.



- 3) Using the metal "L" shape latch (A) as a template, mark its location on the plastic door surround. In order to get more plastic support under the L-latch we recessed the plastic surround by 1/8" inward (B).



If you need more assistance, we are only a phone call away.

(770) 886-2500

Monday-Friday
8:30am-5:30pm EST

GENO'S GARAGE, INC.
1150 Samples Industrial Drive
Cumming, Georgia 30041

- 4) Drill two 11/64" holes into the plastic surround. We used an 11/64" bit because it is a tight/almost threaded hole for the supplied 8mm bolt to pass through.



- 5) Install the L-latch. Tighten the supplied bolts/nuts.



- 6) Cut out a notch in the storage compartment bin so there is clearance for the newly installed L-latch (A).

