

The sample kit that we had for our initial Pilot Fog Light Kit(s) had a wiring installation page. We are at a loss for an explanation as to why the new box(es) do not.

Regardless, the electrical installation of the Pilot fog lights in the Dodge Ram truck is straightforward.

The kit has plug-ins to the lights and interior switch which cannot be mistaken.

Underhood – Relay: RED wire to 12-volt Positive continuous power source; BLACK to ground.

Interior – Fog Light Switch: RED to 12-Volt Positive; ignition-on power source; BLACK to ground.

Note to the '03-'09 Dodge truck owners: As mentioned in our Geno's Garage catalog, you will have to cut the wires that run between the two fog lights and extend the wiring by 24 inches. The one-size-fits-all wires from Pilot did not take into account the wider position of the fog lights on the '03-'09 bumper.

Note to the '94-'02 Dodge truck owners: In order to ADD these fog lights to your truck, you will have to remove the bumper's plastic valance panels and cut the plastic to accept the larger diameter fog light assembly. Although this sounds simple, you also have to remove the bumper to get the valance panel off.



If you need more assistance, we are only a phone call away.

(770) 886-2500

Monday–Friday
8:00am–7:00pm EST

GENO'S GARAGE, INC.
1150 Samples Industrial Drive
Cumming, Georgia 30041