


Installation: MPC Grill Guard and Tool Tray



To install the MPC Grille Guard/Tool Tray, you will need a Phillips-head screwdriver, RTV silicone, and a tube of red thread lock.

Clean the top of the intercooler, and then apply four or five quarter-size areas with RTV silicone. This is used to absorb any vibrations that might loosen the screws.

We recommend that red thread lock be applied to the screws before installation. Tighten the screws. Be careful not to strip the condenser holes. Let the RTV set up per the instructions on the tube, and then you are ready to operate the vehicle.

Use **extreme** care during installation as you can **easily** damage the A/C evaporator core if the screws are installed improperly.



If you need more assistance, we are only a phone call away.

(770) 886-2500

Monday–Friday
8:30am–5:30pm EST

GENO'S GARAGE, INC.
1150 Samples Industrial Drive
Cumming, Georgia 30041