



Locking Fuel Cap for 2000 to 2012 Ram 2500/3500
also fits 2008 to 2018 Ram 3500/4500/5500 Cab & Chassis models


To Install:




- Align the Secure Key over the screw head and slip it on.




- Turn the Secure Key counterclockwise about four revolutions so that the bottom of the screw head is level with top of cap.




- Place unit above the fuel neck.




- Insert C&C 4G Locking Fuel Cap into filler neck and rotate clockwise until it stops.



- Align the Secure Key over the screw head and slip it on.




- Turn the Secure Key clockwise until the screw is lightly tight.




- Remove Secure Key.
C&C 4G Locking Fuel Cap should be securely locked in place.


To Remove:



- Align the Secure Key over the screw head and slip it on.



- Turn the Secure Key counterclockwise about four revolutions so that the bottom of the screw head is level with top of cap.



- Rotate the C&C 4G Locking Fuel Cap counterclockwise and lift out.

Lightly tightening the Secure Screw is enough to ensure a secure system and an easy-to-unlock cap for the future.

C&C 4G LOCKING FUEL CAP Model# GG-EZCC4G